

Fabric Care and Cleaning Instructions

1. Remove dust with a feather type duster or compressed air. A hand-held vacuum with low suction may also be used. Rigorous vacuuming is not recommended as this can distort the fabric.
2. Do not scrub the fabric.
3. Do not use solvents or any abrasive substance which might damage the coating of the fabric including hydrocarbon based cleaners, such as mineral spirits.
4. Clean by gently blotting with a sponge or a soft brush dipped in lukewarm soapy water using mild detergent. If you have mold or mildew, a diluted mixture of 10% Clorox® regular bleach and 90% water may be used to remove the stains. Rinse with clean water. **DO NOT USE STRONG OR RAW BLEACH.** Leave the blind down until completely dry.
5. A dry chemical sponge may also be used for spot cleaning.
6. You can also very gently rub the fabric with a clean white pencil eraser to remove small stains.

Recommended and Tested Cleaner Options

PVC coated fiberglass screens only

1. Simple Green® All Purpose Cleaner, diluted 50% with water
2. White Vinegar, diluted 50% with water.

Special Cleaning Instructions

1. For Flocké, Vela, Vizela and Edessa, **DO NOT USE WATER.** Remove spots with a natural or dry cleaning sponge only.
2. For SilverScreen on the metalized side of the fabric use only a duster, compressed air, or a vacuum at low suction to clean. Using water and blotting the surface can cause the metal to break loose and come off.